


## VCOM DEMO GUIDE FOR ANDROID



### TO DEMO VCOM:

1. Download VCOM Control Panel for Android from [www.intracomsystem.com](http://www.intracomsystem.com) under "Downloads";
2. Once installed touch your VCOM icon to get to the configuration splash screen;
3. Enter a user name of your choice (first name recommended), "vcom" as the password, 'Virtual Matrix IP Address' 216.189.144.41, and touch "Login".

*It is recommended that you schedule a demo with your sales representative as the demo system is not regularly monitored.*

### FIREWALL INFO FOR NETWORK ADMINS:

To connect to the VCOM server set up for demos over the public internet allow a TCP connection for data on port 1000 and UDP connection for audio on port 1000.

### HOW TO LEARN MORE:

- Download VCOM User Guides from the link above for detailed install, config, and use info;
- Contact us at [info@intracomsystem.com](mailto:info@intracomsystem.com) or (818) 357-2347;
- Visit us online at [www.intracomsystem.com](http://www.intracomsystem.com).